


Installation Guide for a Low Profile Adapter Card Chassis



1

Existing Honeywell IPC620 chassis.



2

Field wiring connectors are removed from I/O card.



3

Honeywell chassis is replaced by the Emphatec low-profile adapter chassis. New chassis uses the same mounting holes as the original chassis.



4

Adapters are mounted on DIN rails. Each adapter includes the cable to the new I/O card.



5

Field wiring connectors are re-installed.



6

Hinged cover plate is installed. New I/O system can be mounted on the cover to minimize cable lengths and eliminate the need for additional cabinets. Cover is pre-drilled for the Rockwell Controllogix system.